



Samsung Galaxy Tab 3 10.1 Front-Facing Camera Replacement

Written By: Corey Brown





TOOLS:

- [iFixit Opening Picks set of 6](#) (1)
- [Spudger](#) (1)
- [Tweezers](#) (1)



PARTS:

- [Galaxy Tab 3 10.1 Front Camera](#) (1)

Step 1 — Rear Case



- Insert an opening pick between the rear case and the plastic rim.

i You may need to add multiple picks to detach the clips.

- Slide the pick along the edge of the rear case until you release the plastic clips attaching the rear case to the display.
- Continue to slide the pick around the edge of the rear case until all clips are released.

Step 2



- Lift the case up to remove it.

Step 3 — Front-Facing Camera



- Lift the plastic frame to remove.

⚠ Avoid the three delicate ribbon cables.

Step 4



- Use the flat end of a plastic spudger to pry up the press-fit connector from the motherboard.
- Remove the camera by gently pulling upward with a pair of tweezers.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 12:45:57 AM.